


### **Bi Fury firmware upgrade instruction:**

1. Unzip firmware.zip
2. Unplug device
3. Connect the two pads, as shown in picture



4. While keeping the two pads connected, insert device. After device has been inserted, the green LED should stay off, and you can remove the tweezers.
5. Open up the removable disk window, delete FIRMWARE.BIN, and copy new firmware.bin in its place.
6. Eject device
7. Remove device from USB, and plug it back in without connecting the two pads.